



The eco-friendly alternative decking to hardwood timbers (kwila, Balau, Jarrah etc.) with exceptional low maintenance features.

Transform your garden, courtyard, balcony or patio with this innovative Decking composite tile system now available from Techwood. It is not only affordable but is also very easy to install yourself.

It is suitable for all outdoor applications, such as courtyards or verandahs, as well as for saunas, spas, shower or pathways — the possibilities are endless.

The refreshing cool grey colour or the warmer cedar colour combine well with crisp white pebbles for the modern earthy look or if using the TechTile system over a grassed area, consider substituting the pebbles for mondo grass. TechTile can also be installed as individual pavers without a visible joining system.

The system consists of square composite tiles that are quickly and easily pressed into the interlocking joiner. Each pack consists of 4 tiles 45x45cm and the interlocking joiners come in a pack of 6.



**TechTile 4545 Cedar**

Size: 45x45 x 2.2cm

Colour: Cedar

Code: 4545C – Cedar



**TechTile 4545 Grey**

Size: 45x45 x 2.2cm

Colour: Grey

Code: 4545G – Grey





Straight pattern



Cross pattern



Straight pattern,  
mixed colours

### Hardware and tools required

Installation is easy — all you need is a utility knife, hand saw, Phillips head screwdriver and a tape measure.

The area to be covered by the TechTiles should be a hard, flat and level surface with adequate drainage. Balconies and concrete surfaces are suitable. If installing on grass, gravel should be used to level the surface and provide drainage.

### Patterns

Tiles can be laid either in a straight or cross pattern

### Hints

When the tile is too large,....

- Measure the size you need the TechTile to be
- Flip the tile over and unscrew one for more of the slats
- Cut the slat to fit and re-attach to the Techtile

You can use the slat as a guide when sawing the tile down



- Start at one corner of the area to be tiled
- Place the joining clip on the floor
- On the underside of every corner of the tile is a pre-drilled hole. Align the pre-drilled hole with a pin on the Square Joiner and press fit. This can simply be done underfoot. Repeat for other Joiners
- To remove the exposed area of the Square Joiners, use a utility knife
- On the underside of the Square Joiners are grooves that can be used as cutting guides
- Stroke along the groove using the knife and snap off the Joiner
- Keep any excess clips in case you need them



Once the first Techtile is laid, you can begin adding additional tiles

- Add one Square Joiner to the corner of each tile
- Work in an outward direction until the area is covered